

H·R·M

HA-5118

HA-5344

HA-5321

HA-5522

HA-5203

HA-5151

HA-5152

HA-5366

HA-5322

HA-5544

HA-5161

HA-5377

HA-5341

HA-5566

HA-4005


WWW.HRM2003.COM

Contents

Overview	A
Main features	1
Daylight saving time	1
Main functions of the keys	2
Selecting a city	3
Adding new city	4
Setting the time and date	5
Setting daily alarm	6
Choose muazzen	7
Setting eqamah	8
Azan edit	9
Azan ON/OFF	10
Azan taqweem systems	11
Frequently asked questions	12-13

Overview

A



HA-5118 DC12V 1A	HA-5344 DC12V 2A	HA-5321 DC12V 2A	HA-5522 DC12V 2A	HA-5203 DC12V 2A
HA-5151 DC12V 1A	HA-5366 DC12V 2A	HA-5322 DC12V 2A	HA-5544 DC12V 2A	
HA-5161 DC12V 1A	HA-5377 DC12V 2A	HA-5341 DC12V 2A	HA-5566 DC12V 2A	HA-4005 DC12V 1A

1

Main features

-  ▶ complete azan for all prayers(with volume control)
-  ▶ prayer times for most cities in the world.
with azan taqweem system.
-  ▶ could modify the different prayer time easily in
the outskirts of cities.
-  ▶ the possibility turn on or off azan sound separately
-  ▶ could easily use latitude , longitude and GMT to
add a new city.
-  ▶ temperature
-  ▶ Hijri and Gregorian calendars
-  ▶ daylight saving time option

Daylight saving time

To set the Daylight Saving Time (DST) press  for any city.

Then will display light behind the time on the clock.
Notice that the time and azan times are increased
by one hour.

To get back to standard time, press  button then the light off and the time and the azan times will decrease by an hour.

Notes

If DST no work, means your country doesn't have daylight saving time.

Main functions of the keys

2

-  **Led light:** To adjust led light
-  **Language:** To choose English or Arabic
-  **City:** To select the city
-  **Time:** To set time and date
-  **Next:** To move during setting
-  **UP:** To convert the temperature between °C and °F
-  **UP:** Increase the number
-  **Down:** Decrease the number
-  **DST:** Daylight saving time (convert between summer and winter time)
-  **G ⇌ H:** Convert between Hijri and Gregorian calendar
-  **12 ⇌ 24:** Switch 12 or 24 hours format
-  **Azan:** Press AZAN to set azan safety time
-  **Azan:** Press AZAN twice to select taqweem system
-  **AZAN ON/OFF:** Turn on or off azan sound
-  **VOICE+:** To turn up the voice
-  **VOICE -:** To turn down the voice
-  **Eqamah:** To set the rest time to pray
-  **Jumuah:** To set jumuah time
-  **D/ALM:** To set daily alarm
-  **8 muazzen:** To choose multiple azan sound
-  **EXIT:** Exit and finish setting

3

Selecting a city

To select a city, follow the steps as below.

To select a city, follow the steps below:

1 Press **CITY**  country name will display.

(or press "CITY" using remote controller, country name will display.)

2 Use **UP**  or **DOWN**  to select the country,
then press **NEXT** .

3 Then use **UP**  or **DOWN**  to select the city.

4 To finish setting press **NEXT** .

SAUDI ARABIA

ميلادي GREG 966- 12 هجري HJRI

MAKKAH

ميلادي GREG 966- 12 هجري HJRI
4

Notes

When setting any number in the clock, that number will be flashing

Adding new city

4

***This clock can be used anywhere around the world. You can select your city directly by selecting from city list.**

***If your location is not one of the major listed cities your location can be added to the list of cities as [NEW CITY] using latitude, longitude and GMT information.**

For example, the following steps show how to set the city of AT TAIF in Saudi Arabia as follow:

1 Long press  "NEW CITY" will display (or press "NEW CITY" using remote controller)

2 Press , use  or  to adjust latitude [21], press , use  or  to adjust minutes [25].

3 Press , use  or  to adjust longitude [40], Press , use  or  to adjust minutes [41].

4 Press , use  or  to adjust GMT hour [GMT+3:00], Press , use  or  to adjust GMT minutes [GMT+3:00].

5 Then Choosing Taqweem System.

6 To finish setting press .

NEW CITY

ميلادي GREG

هجري HIRJI

NEW CITY

LATITUDE

الإقامة EQAMAH

الفجر AL FAJR

الشر و قن الضحى AL DHRU A/SHURUQ

الأذان AZAN

LONGITUDE

الظهر AL ZHHR

العصر AL ASR

GMT

المغرب MAGRIB

العشاء AL ISHA



Notes

*If you find any difference after setting new city, you can edit azan **page 8**

*If you want to know more about information of the city setting, please visit: www.userguide.hk>>city selection

Setting the time and date

To set the time and date, as follow:

1 Press **TIME** one time, "HOUR" will display.

الوقت

2 Use **UP** or **DOWN** to adjust the hour, then press **NEXT** (notice the AM/PM indicators), "MINUTE" will display.

أعلى
أسفل

التالي

3 Use **UP** or **DOWN** to adjust the minute, then press **NEXT**, "YEAR" will display.

أعلى
أسفل

التالي

4 Use **UP** or **DOWN** to adjust the year, then press **NEXT**, "MONTH" will display.

أعلى
أسفل

التالي

5 Use **UP** or **DOWN** to adjust the month, then press **NEXT**, "DAY" will display.

أعلى
أسفل

التالي

6 Use **UP** or **DOWN** to adjust the day

أعلى
أسفل

7 If you need "+" or "-" hijri day, press **NEXT**, use **UP** or **DOWN** to adjust.




التالي

أعلى

أسفل

8 To finish setting press **NEXT**

التالي



Setting daily alarm

6

Setting daily alarm rings regularly at the same time everyday.

Setting the daily alarm is shown below:

1 Press **D/ALM**  one time, "**HOUR**" will display.

2 Use **UP**  or **DOWN**  to adjust the hour, then press **NEXT** , "**MINUTE**" will display.

3 Use **UP**  or **DOWN**  to adjust the minute, then press **NEXT** , "**SAT OFF**" will display

4 Use **UP**  or **DOWN**  to select TURN ON/OFF Saturday alarm, then press **NEXT** , to select the sounds


5 Then press **NEXT**  to TURN ON/OFF other days alarm and select the sounds.

6 To finish setting press **NEXT** 



SAT OFF

SOUND 5



7

Choose muazzen

To choose the muazzen is shown below:

1 Press **8** ^{8 MUAAZEN} will display "SELECT MUAAZEN VOICE" then press **NEXT** ^{التالي}.

2 Use **UP** ^{أعلى} or **DOWN** ^{أسفل} to choose Al fajr muazzen sound, press **NEXT** ^{التالي}, use **UP** ^{أعلى} or **DOWN** ^{أسفل} to TURN ON/OFF DOAA, then press **NEXT** ^{التالي}.

3 Use **UP** ^{أعلى} or **DOWN** ^{أسفل} to choose AL zuhr muazzen sound, press **NEXT** ^{التالي}, use **UP** ^{أعلى} or **DOWN** ^{أسفل} to TURN ON/OFF DOAA, then press **NEXT** ^{التالي}.

4 Use **UP** ^{أعلى} or **DOWN** ^{أسفل} to choose AL asr muazzen sound, press **NEXT** ^{التالي}, use **UP** ^{أعلى} or **DOWN** ^{أسفل} to TURN ON/OFF DOAA, then press **NEXT** ^{التالي} to choose other prayer time muazzen...etc.

5 To finish setting press **NEXT** ^{التالي}.

SELECT MUAAZEN VOICE

ميلادي GREG هجري HIJRI

الإقامة EQAMAH **04:38** الفجر AL FAJR **04:13**

05:49 البشور والضحى AL DHUH'A/SHURQ **05:39**

...

AM PM

AL FAJR

ميلادي GREG **DOAA OFF** هجري HIJRI

الإقامة EQAMAH **04:38** الفجر AL FAJR **04:13**

...


AM PM

DOAA OFF

ميلادي GREG **DOAA OFF** هجري HIJRI

الإقامة EQAMAH **04:38** الفجر AL FAJR **04:13**

...




Setting eqamah


8

Setting the eqamah is shown below:

- 1 Press  use  to adjust the Al fajar eqamah, then press .



- 2 Use  or  to select "FOLLOWING AZAN" or "FIXED EVERYDAY", then press  to adjust Al zuhr eqamah, etc...



Notes:

FOLLOWING AZAN:

means the eqamah will change automatically with azan time.


FIXED EVERYDAY:

means the eqamah will be fixed same time everyday.

Setting jumuah

Setting the jumuah is shown below:

- 1 Press , then press .
- 2 Use  to backward 99 minutes Jumuah time.
- 3 Press , Use  or  to select "FOLLOWING AZAN" or "FIXED EVERYDAY".
- 4 To finish setting press .



Notes

Long press "JUMUAH" can turn off.

(Press **JUMUAH ON/OFF**, when using remote controller.)


As needed, any azan time can be adjusted forward or backward by a fixed number of minutes as follows.

- 1** Press  one time, "AZAN EDIT" will display.


- 2** Use  or  to edit Al Fajr azan, then press .

- 3** Use  or  to edit Al shurq azan, then press  to edit other azan.

- 4** To finish setting press .



الإقامة EQAMAH	الفجر AL FAJR	الشرق/الشروق AL DHUN A/SHURQ	الظهر AL ZUHR	العصر AL ASR	المغرب MAGRIB	العشاء AL ISHA
	04:13					
	05:39					
	12:22					
	15:40					
	19:04					
	21:04					



Notes

After selecting any city, the azan safety times are all reset and need to be readjusted.

Azan ON/OFF

10

At this clock, you can turn on or off the azan voice for every pray time as the following steps.

1 Press  .
أذان

2 Use  or  to turn on/off Al Fajr Azan sound, then press  to turn on or turn off other Azan sound, etc...

AZAN ON

ميلادي
GREG
AZAN ON
هجري
HJRI

الإقامة EQAMAH		الاذان AZAN
	الفجر AL FAJR	04:13
	الشرق / الضحى AL DHUR / SHURQ	05:39
	الظهر AL ZUHR	12:22
	العصر AL ASR	15:40
	المغرب MAGRIB	19:04
	العشاء AL ISHA	21:04

3 To finish setting press  .
التالى

Notes

When you close the azan voice you will notice that the signal (●) will disappear at the side of prayer time.

Fajr and Isha times are calculated by either an angle of the sun below the horizon or by an interval of time. This clock is programmed to use the local method or the most widely used system for your city. However, you can change another system as follow.

* Press **●** ^{AZAN}_{الاذان} twice then use **●** ^{UP}_{اعلى} or **●** ^{DOWN}_{اسفل} to select.

df Local tapweem

10:10 MANUALLY

H Hanafi

20:18 NUSANTARA

19:30 UM ALQURA

19:17 Egyptian taqweem (egypt)

15:15 Union is Islamic society of North America (isna)

18:18 University of Science Islamic in Karachi (Hanafi taqweem)

18:17 Muslim world league (muslim league)

1:30 Fixed time, fajr time is determined as a fixed interval of time before shrooq time. Isha time is determined as a fixed interval of time after magrib azan. This system is used in Northern Europe.

Notes

After selecting a new city, the clock will be reset to use the original programmed azan calculation method for the new city.

Frequently asked questions

12

Q:I want to adjust the clock on my city,but I did not find the city within the “List of cities” ?

A:Look for your city in the city's page or website,and if you do not find your city on the website,you can select your neighboring city code or send an e-mail to info@al-harameen.com explaining the name of your city and your country.

Q:In my city, the time of Fajr Azan is specific of a fixed period of 1:40 before sunrise. In respect of isha,also is specific of a fixed period of 1: 45 after maghrib time.How do I set this system?

A:First,select fixed 1:30 Taqweem system,refer to taqweem system and then manually adjust the reserve time of Azan of Azan Fajr by 10 minutes and Isha by 15 minutes see azan edit setting .Pls refer to P 9.

Q:My country uses the system of Daylight saving time(DST).When changing by one hour,how can i re-set the clock?

A:You need to select daylight saving time option (DST on),pls.refer to P1

Q:Why there is a difference of one hour in times of prayer “Azan” ?

A:Make sure the daylight saving time option (DST on or off) Pls.refer to P1.

Q:My clock doesn't play in the proper timing specially Fajr Azan?

A:Make sure that the time is AM or PM when set.

Q:How can I convert temperature from Fahrenheit to Centigrade?

A:Press the button “UP” when normal position, but this feature is only in some models.

Q:Hijri and Gregorian date is exchanged every 10 seconds, is it possible to install one of them?

A:Yes,you can press the button “H/G” , as 3 pressing for Gregorian date, and 2 pressing for Hijri date.