

H·R·M

HA-5125 HA-5120 HA-5115 HA-4008 HA-4003



WWW.HRM2003.COM

Contents

Overview	A
Main features	1
Daylight saving time	1
Main functions of the keys	2
Selecting a city	3
Adding new city	4
Setting the time and date	5
Setting daily alarm	6
Choose muazzen	7
Setting eqamah	8
Azan edit	9
Azan ON/OFF	10
Azan taqweem systems	11
Frequently asked questions	12-13
City codes	14-33

Overview

A



12V 1A

Main features

-  ▶ 1-complete azan for all prayers(with volume control)
-  ▶ 2-prayer alarms to remind of all prayers at Iqamah or salat time
-  ▶ 3-prayer times for most cities in the world. with azan taqweem system.
-  ▶ 4-could use easily according to international telephone code especially in al-haramain
-  ▶ 5-could modify the different prayer time easily in the outskirts of cities.
-  ▶ 6-the possibility turn on or off azan sound separately
-  ▶ 7-temperature
-  ▶ 9-Hijri and Gregorian calendars
-  ▶ 10-daylight saving time option

Daylight saving time

To set the Daylight Saving Time (DST) press  for any city.

Then will display light behind the time on the clock. Notice that the time and azan times are increased by one hour.

To get back to standard time, press  button then the light off the time and the azan times will decrease by an hour.

Notes

If DST not work, means your country doesn't have daylight saving time.

Main functions of the keys

2

-  **Led light:** To adjust led light
-  **Language:** To choose English or Arabic
-  **City:** To select the city
-  **Time:** To set time and date
-  **Next:** To move during setting
-  **UP:** To convert the temperature between °C and °F
-  **UP:** Increase the number
-  **Down:** Decrease the number
-  **DST:** Daylight saving time (convert between summer and winter time)
-  **G ⇌ H:** Convert between Hijri and Gregorian calendar
-  **12 ⇌ 24:** Switch 12 or 24 hours format
-  **Azan:** Press AZAN to edit azan time
-  **Azan:** Press AZAN twice to select taqweem system
-  **AZAN ON/OFF:** Turn on or off azan sound
-  **VOICE+:** To turn up the voice
-  **VOICE -:** To turn down the voice
-  **Iqamah:** To set the rest time to pray
-  **Jumuah:** To set jumuah time
-  **D/ALM:** To set daily alarm
-  **8 muazzen:** To choose multiple azan sound
-  **EXIT:** Exit and finish setting

3

Selecting a city

To select a city, look up the international telephone code of your city(see page no.14-33)and follow the steps below.

1 Press **CITY**  country code will display

المدينة
CITY

2 Use **UP**  or **DOWN**  to select the country

أعلى
UP

أسفل
DOWN

code then press **NEXT** 

التالي
NEXT


3 Then use **UP**  or **DOWN**  to select the city

أعلى
UP

أسفل
DOWN

4 To finish setting press **EXIT** 

خروج
EXIT



Notes

When setting any number in the clock , that number will be flashing

Adding new city

4

*This clock can be used anywhere around the world. You can select your city directly by selecting from city list.

*If your location is not one of the major listed cities your location can be added to the list of cities as [NEW CITY] using latitude, longitude and GMT information.

For example, the following steps show how to set the city of AT TAIF in Saudi Arabia as follow:

1 Long press **CITY** "المدينة" will display

2 Press **NEXT**, use **UP** or **DOWN** to adjust

latitude [21], press **NEXT**, use **UP** or **DOWN** to adjust minutes [25].

3 Press **NEXT**, use **UP** or **DOWN** to adjust

longitude [40], Press **NEXT**, use **UP** or **DOWN** to adjust minutes [41].

4 Press **NEXT**, use **UP** or **DOWN** to adjust

GMT hour [GMT+3:00], Press **NEXT**, use **UP** or **DOWN** to adjust GMT minutes [GMT+3:00].

5 To finish setting press **NEXT**.

NEW CITY

ميلادي GREG

هجري HJRI

LATITUDE

الإقامة EQAMAH

الفجر AL FAJR

الشر و قن الضحى AL DHRH A/SHURH

LONGITUDE

الظهر AL ZHRH

العصر AL ASR

GMT

المغرب MAGRIB

العشاء AL ISHA

Notes

*If you find any difference after setting new city, you can edit azan **page 9**

*If you want to know more about information of the city setting, please visit: www.userguide.hk>>city selection

Setting the time and date

To set the time and date, as follow:

1 Press **TIME** one time, "HOUR" will display.

الوقت

2 Use **UP** or **DOWN** to adjust the hour, then press **NEXT** (notice the AM/PM indicators), "MINUTE" will display.

أعلى
أسفل

التالي

3 Use **UP** or **DOWN** to adjust the minute, then press **NEXT**, "YEAR" will display.

أعلى
أسفل

التالي

4 Use **UP** or **DOWN** to adjust the year, then press **NEXT**, "MONTH" will display.

أعلى
أسفل

التالي

5 Use **UP** or **DOWN** to adjust the month, then press **NEXT**, "DAY" will display.

أعلى
أسفل

التالي

6 Use **UP** or **DOWN** to adjust the day

أعلى
أسفل

7 If you need "+" or "-" hijri day, press **NEXT**, use **UP** or **DOWN** to adjust.




التالي

أعلى

أسفل

8 To finish setting press **NEXT**

التالي



Setting daily alarm

6

Setting daily alarm rings regularly at the same time everyday.

Setting the daily alarm is shown below:

1 Press **D/ALM**  one time, "**HOUR**" will display.



2 Use **UP**  or **DOWN**  to adjust the hour, then press **NEXT** , "**MINUTE**" will display.

3 Use **UP**  or **DOWN**  to adjust the minute, then press **NEXT** , "**SAT OFF**" will display.

4 Use **UP**  or **DOWN**  to select TURN ON/OFF Saturday alarm, then press **NEXT** , to select the sounds.

5 Then press **NEXT** , to TURN ON/OFF other days alarm and select the sounds.

6 To finish setting press **NEXT** .



Choose muazzen

To choose the muazzen is shown below:





1 Press **SMUAZZEN** will display "SELECT MUAZZEN VOICE" then press **NEXT**.

2 Use **UP** or **DOWN** to choose Al fajar muazzen sound, press **NEXT**, use **UP** or **DOWN** to TURN ON/OFF DOAA, then press **NEXT**.

3 Use **UP** or **DOWN** to choose AL zuhr muazzen sound, press **NEXT**, use **UP** or **DOWN** to TURN ON/OFF DOAA, then press **NEXT**.

4 Use **UP** or **DOWN** to choose AL asr muazzen sound, press **NEXT**, use **UP** or **DOWN** to TURN ON/OFF DOAA, then press **NEXT** to choose other prayer time muazzen...etc.

5 To finish setting press **NEXT**.




Setting eqamah

8

EQAMAH means count rest time to Iqamah(pray start), follow the steps below to set:

- 1 Press **EQAMAH**  **الإقامة**
- 2 Use **UP**  or **DOWN**  to adjust Alfajr Iqamah, then press **NEXT**  **التالي**
- 3 Use **UP**  or **DOWN**  to adjust Dhuhr Iqamah, the press **NEXT**  **التالي** for others, etc.

- 4 To finish setting press **EXIT**  **خروج**



EXIT خروج

Notes

If you don't set Eqamah option, the clock will automatically count minutes after current azan (up to 30 minutes)

9

Azan edit

As needed, any azan time can be adjusted forward or backward by a fixed number of minutes as follows.

1 Press **●** ^{AZAN} one time, "SAFE 74"
الاذان
will display.

2 Use **UP** ^{اعلى} or **DOWN** ^{اسفل} to edit Al Fajr
azan, then press **●** ^{NEXT} ^{التالي}.

3 Use **UP** ^{اعلى} or **DOWN** ^{اسفل} to edit Al shurq
azan, then press **●** ^{NEXT} ^{التالي} to edit
other azan.

4 To finish setting press **●** ^{NEXT} ^{التالي}

Notes

After selecting any city, the azan safety times are all reset and need to be readjusted.


Azan ON/OFF

10

At this clock, you can turn on or off the azan voice for every pray time as the following steps.

1 Press  .
أذان

2 Use  or  to turn on/off Al Fajr Azan sound, then press  to turn on or turn off other Azan sound, etc...



3 To finish setting press  .
التالي

Notes

When you close the azan voice you will notice that the signal (●) will disappear at the side of prayer time.

Fajr and Isha times are calculated by either an angle of the sun below the horizon or by an interval of time. This clock is programmed to use the local method or the most widely used system for your city. However, you can change another system as follow.

* Press **●** ^{AZAN}_{الاذان} twice then use **●** ^{UP}_{اعلى} or **●** ^{DOWN}_{اسفل} to select.

dF Local tapweem

10:10 MANUALLY

H Hanafi

20:18 NUSANTARA

19:30 UM ALQURA

19:17 Egyptian taqweem (egypt)

15:15 Union is Islamic society of North America (isna)

18:18 University of Science Islamic in Karachi (Hanafi taqweem)

18:17 Muslim world league (muslim league)

1:30 Fixed time, fajr time is determined as a fixed interval of time before shrooq time. Isha time is determined as a fixed interval of time after magrib azan. This system is used in Northern Europe.

Notes

After selecting a new city, the clock will be reset to use the original programmed azan calculation method for the new city.

Frequently asked questions

12

Q:I want to adjust the clock on my city,but I did not find the city within the “List of cities” ?

A:Look for your city in the city's page or website,and if you do not find your city on the website,you can select your neighboring city code or send an e-mail to info@al-harameen.com explaining the name of your city and your country.

Q:In my city, the time of Fajr Azan is specific of a fixed period of 1:40 before sunrise. In respect of isha,also is specific of a fixed period of 1: 45 after maghrib time.How do I set this system?

A:First,select fixed 1:30 Taqweem system,refer to taqweem system and then manually adjust the reserve time of Azan of Azan Fajr by 10 minutes and Isha by 15 minutes see azan edit setting .Pls refer to P 9.

Q:My country uses the system of Daylight saving time(DST).When changing by one hour,how can i re-set the clock?

A:You need to select daylight saving time option (DST on),pls.refer to P1

Q:Why there is a difference of one hour in times of prayer “Azan” ?

A:Make sure the daylight saving time option (DST on or off) Pls.refer to P1.

Q:My clock doesn't play in the proper timing specially Fajr Azan?

A:Make sure that the time is AM or PM when set.

Q:How can I adjust the Azan alarm to remind after or before azan every day.

A:Hereby,we suppose that the next Fajr shall come at 5:00 AM, hence you can set the alarm prayer at 5:15 AM,there after the alarm of Fajr Azan shall be automatically run 15 minutes later every day.

Q:How can I convert temperature from Fahrenheit to Centigrade?

A:Press the button “UP” when normal position, but this feature is only in some models.

Q:Hijri and Gregorian date is exchanged every 10 seconds, is it possible to install one of them?

A:Yes,you can press the button “H/G” , as 3 pressing for Gregorian date, and 2 pressing for Hijri date.